



3305 Breckinridge Blvd. Suite 122
Duluth, GA 30045
1-800-426-6256 770-243-2617

Taper Extension

Operation and Maintenance Guide

“How Professionals Finish The Job”



Operation

The Taper Extension is used to extend the length of our standard taper by 2 feet.

To install the extension, first locate the female extension coupler located at the top of the Extension. To remove the coupler, simply unsnap the clamps. Next, remove the tube protector from the bottom of your TapeTech Taper and replace with the extension coupler. The four holes on the coupler need to line up with four of the five holes at the bottom of the taper tube (there is only one way they will line up). Screw the coupler onto the bottom of the taper using the screws and lockwashers that are currently attached to the coupler.

To attach the Extension to the taper, simply line up the tab on the male coupler of the extension to the slot on the female coupler now installed on the taper and clamp tight. Next, wrap the extension band around the taper control tube and snap shut. Finally, attach the the snap hook on the Extension creaser connector to the S-hook on the creaser wheel trigger of your taper.

The extended taper is operated the same as the standard taper. Hold the extended taper just below the tape spool and at the butt of the extension. Tape cutting and advancing is performed by using the control extension

Maintenance

Clean thoroughly after every use with a brush and water (or water hose) to remove all joint compound from the tool. After the tool is clean, lightly oil with Ames Bazooka® oil or any light machine oil.



3305 Breckinridge Blvd. Suite 122
Duluth, GA 30045
1-800-426-6256 770-243-2617

Extensión de Encintadora

Guía De Uso y Mantenimiento

"Como el Profesional Termina el Trabajo"



Funcionamiento

La extensión de encintadora está diseñada para extender el alcance de la encintadora por 2 pies.

Para instalar la extensión, primero localice el acoplador femenino de la extensión que se encuentra en la parte de arriba de la extensión. Para remover el acoplador, simplemente desabroche las pinzas. Luego, remueva el tubo protector de abajo de la encintadora TapeTech y replácelo con el acoplador de la extensión. Los 4 hoyos en el acoplador deben alinear con 4 de los 5 hoyos en la parte de abajo del tubo de la encintadora (solo hay una manera en que se pueden alinear). Atornille el acoplador a la parte de abajo de la encintadora utilizando los tornillos y arandelas de cierre que se encuentran adjuntos al acoplador.

Para sujetar la extensión a la encintadora, hay que alinear la pestaña de el acoplador masculino de la extensión con la ranura del acoplador femenino ya instalado en la encintadora y cerrar las pinzas firmemente. Luego, envuelva la banda de la extensión alrededor del tubo de control de la encintadora y abroche firmemente. Finalmente, sujete el broche del gancho del conector de la extensión al gancho S del disparador de la rueda de pliegue de la encintadora.

La encintadora extendida funciona igual que la encintadora estándar. Sostenga la encintadora extendida un poco abajo del carrete de cinta y del extremo bajo de la extensión. El corte y avance de cinta es realizado usando el control de la extensión.

Mantenimiento

Limpie a fondo con cepillo y agua o una manguera para eliminar todo residuo de mezcla de la herramienta. Una vez limpia la herramienta, engrásela ligeramente con aceite Ames Bazooka® Oil o cualquier lubricante de máquina ligero.